

# SUPPLYPAK

## PACKAGING AND USE INSTRUCTIONS

THE INSTRUCTIONS MUST BE FOLLOWED FOR SAFE PACKAGING, STORAGE AND USE OF THIS PRODUCT

### Required Safety Supplies:

Veolia recommends the user of this product to utilize proper personal protective equipment compatible with the chemicals involved.

### Customer Service:

1-888-669-9725 Monday – Friday- 8am-5pm CST

### EXTRA SMALL SPILL KIT (APPLIES TO SUPPLY-555)

- This kit is to be used on 1 small spill. Do NOT this kit for spills involving Hydrofluoric Acid (HF).

### Kit Contains:

- |                            |                                 |
|----------------------------|---------------------------------|
| (1) Safety Faceshield/Mask | (1) Resealable Disposal Bag     |
| (1) Pair of Nitrile Gloves | (1) Orange Scoops with Scrapers |
| (1) Blank Contents Labels  | (1) Instruction document        |
| (1) Small Solidifier       | (1) Bleach Disinfecting Wipes   |
| (1) Poly Apron             | (1) Pair of Shoe Covers         |

### How to Use the Universal Mini Spill Kit

1. Evacuate people from the spill area if needed.
2. Open Spill Kit and put on personal protective equipment, (PPE).
3. Sprinkle solidifier on spill.
4. Once spill has been absorbed collect saturated solidifier using the orange scoop and detachable scraper. Place all contents in disposal bag.
5. Clean surface with disinfecting wipes and place in disposal bag.
6. Reseal bag closed and label using the blank contents label.
7. Dispose of used articles according to your organizations protocol and local, state and federal regulations
8. Prepare for the future- if you are down to your last disposal bag, scooper, etc. it may be time to place an order for a new Extra Small Spill Kit.

**NOTE: Depending on the extent of the clean-up process, additional equipment may be required. Veolia is not responsible for accidents occurring with this product, even when proper handling procedures have been followed.**